

Considerations when using U-WAVE fit with Bluetooth®

- What to do if the connection is lost when the U-WAVE is used outside of the communication range

[Note]

The U-WAVE does not automatically connect when in communication range. Re-connect the U-WAVE manually.

[How to connect]

When the Data button is pressed in the disconnected (unconnected) state, the LED flashes in orange repeatedly. The signal is being output in the state of waiting for connection.

When the connection with the receiving terminal is successfully completed, the LED starts flashing in green. If the connection fails, the LED flashes in red.



Flashing orange (waiting for connection)



Flashing green (connection complete)



Flashing red (connection failure)

*If the connection fails, refer to the troubleshooting described in the manual (99MAL126B). Check separately how to operate the receiving terminal (PC, tablet, etc.).

■When there are multiple connectable models within communication range

[Note]

If there are multiple receiving terminals (PC, tablet, etc.) with the same U-WAVE-TCB/TMB information within communication range during connection (re-connection), **it is impossible to control which receiving terminal is connected.**

⇒ Even if the U-WAVE-TCB/TMB is successfully connected (LED flashing in green), it may be connected to another terminal and data cannot be input to your terminal.

[Troubleshooting]

When replacing the receiving terminal, ensure that there is no connection information left in the previous receiving terminal.

Perform the following operations so that only the receiving terminal you wish to connect to is enabled.

- Turn off the Bluetooth function of the receiving terminal that does not require connection*.
- Delete U-WAVE-TCB/TMB information from the receiving terminals that do not require connection*.
- Connect to the terminal.

*Check separately how to operate the receiving terminal (PC, tablet, etc.).

U-WAVE-TCB/TMB information (ID No.) is described on the side of the main product.

